



1. Drill four 7/8" dia. holes, 2-1/2" deep at locations marked from Simme-Seat anchor template.

2. Clean holes with pressurized air.

3. Insert anchors and drive flush with surface of concrete.

4. Expand anchors with setting tool. Anchor is properly expanded when shoulder of setting tool is flush with top of anchor.

FIGURE 2 – ANCHOR INSTALLATION INSTRUCTIONS